



CREDIT CARD

e-range credit card - accept credit cards right at your dispenser

Site Requirements - (what is needed at the location)

e-range credit card hardware requires:

- An existing computer to 'listen' to the ball dispenser and credit card reader at the ball dispenser
- that computer needs a high speed internet connection.

In order to process credit card requests, the e-range software that connects through the internet needs an account with either:

1. An account with ETS Corporation for credit and/or gift card processing
ETS Corporation: 1 (800) 834 – 7790
<http://www.etscorporation.com>
2. An account with Hypercom Payment Solutions for credit card processing server software
Hypercom Payment Solutions: 1 (425) 882 – 0921

You can phone each of these companies for credit card rates. Explain that you will be using e-range's Credit Card System and how you could go about setting up an account. ETS is generally similar, if not less expensive, than your current processor. Hypercom uses a minimal annual fee to connect to their services, however you use your current credit card processor and your current rates if you use Hypercom.

Dispenser Requirements - (what is needed in the dispenser)

- 120 VAC outlet inside the ball dispenser
- 1 separate cutout - standard size 4"x4.25" and bolt pattern used by a Bill Validator
- Environmentally clean space inside the dispenser for the additional hardware
- Environmentally protected- dispenser should be in a shed or at least protected from direct exposure to the elements.
- Maximum 1000ft if wireless

Additional Hardware - (what will go in the dispenser)

- A UPS (Universal Power Supply) that will regulate and filter power is recommended so that clean power is available for all the sensitive additional electronics

Call Scott at e-range if you have any questions regarding set up or site requirements. 905 688-8823